



To Install the Peek-a-boom PB3 In later Rogators, simply follow the control wiring from the control stick to the connector as shown above. Separate the connector and install the connectors from the PB3 as shown, being sure to match the correct gender plug to each. As long as the pairs match, the connection cannot be made incorrectly.